





Digital Wall Clock User Manual



Contents

1. Installation	-----	1
2. First use	-----	2
3. Overview	-----	3-4
4. Time Set	-----	5
5. Alarm Set	-----	6-7
6. Temperature	-----	7
7. Screen brightness, Font Colors, Night light	-----	8
8. Countdown, Volume Setting	-----	9
9. Daylight saving time	-----	10
10. Settings with device buttons	-----	11-12
11. FAQ	-----	13
12. Warranty	-----	14

Installation




1. Align the positioning hole to nail the hanging nail to the wall.
2. Hang the alarm clock on the nail.
3. Installation completed

Start to power on





Power on for the first time

Connect the DC power plug to the back connector of the alarm clock, and the USB plug at the other end is connected to the charging head to plug into the 100V-240V home socket. As shown in the following figure:




This alarm clock must work with power adapter. We provide lifetime warranty for every customer. We strongly recommend you to contact us with your order ID to activate the warranty. You can also visit www.jall-us.com to activate lifetime warranty. If missing any accessories, please contact us for replacements.

Device Overview



Remote Control Overview



Time Setting (by remote control)

Note: we strongly recommend to set with remote control for the whole setting.

1. Press to select **12-Hour** or **24-Hour** mode according to your habits.
2. Press to turn on AUTO DST, it's for daylight saving time area.
If you don't need it, just ignore this step.
3. Press to enter the time setting, you will set in sequence for













Hour > Minute > Year > Month > Date

4. The "Hour" is flashing, press to select value. Press and next.
5. Then "Minute" is flashing, press to select value. Press and next.
6. Then "Year" is flashing, press to select value. Press and next.
7. Then "Month" is flashing, press to select value. Press and next.
8. Then "Date" is flashing, press to select value.

Press to finish time setting.

Note: You don't have to set the day of the week. It's calculated automatically.
If you find the day is wrong, it's most likely you've set a wrong "YEAR".
When you turn on Auto DST, time will auto adjust on March and November.
If you don't need auto DST, please turn it off.

Alarm Setting (by remote control)



1. Press  to activate / inactivate alarm #1. You will see the icon  appears, that means alarm #1 is activated, while disappears means alarm #1 is inactivated.
2. Press  to enter the alarm #1 setting, you will set in sequence for **Alarm Hour > Minute > Alarm Mode** (MON-SUN, MON-FRI, SAT-SUN).
3. The “Hour” is flashing, press   to select value. Press  and next.
4. Then “Minute” is flashing, press   to select value. Press  and next.
5. Then select your alarm mode. There're 3 modes to choose from.
 - 1-7 means alarm works for Monday to Sunday (every day).
 - 1-5 means alarm only works for Monday to Friday.
 - 6-7 means alarm only works for Saturday to Sunday.Then press  to finish alarm setting. Alarm #2 is the same.
6. You can press   to adjust alarm volume from **OFF** and V01 to V05.

Attention: If you find the alarm turned on unexpectedly and you don't need it, please set the volume to “OFF”. Sometimes other home device remote signal, like TV will influence the clock alarm.

How to stop alarm?


1. When the alarm goes off, press any buttons on remote control to stop the alarm. It will go off the next day.
2. Without any operation, the alarm will ring for 20 minutes and stop automatically. It will still go off the next day.

Note: If you want to disable the alarm permanently,

press  or  to turn it off so that it won't go off the next day.



You will see the alarm icon   disappear on the screen.

Temperature Unit




Press  to change temperature from C° to F°.

Note: The temperature is detected by the sensor inside the clock. You can't set it manually.

Screen Brightness

1. In the time display state, press  to adjust the screen brightness from High -> Low -> High.
2. You can also press  auto-dimmer button to auto adjust the screen brightness. In this mode, the brightness will auto change according to the environment light, makes it dimmer at night and brighter at daytime. It shows “ON”, which means it’s turned ON, while “OFF” means it’s turned OFF.



Font Displaying Colors & Night Light



1. Press  to change letter colors. If you want to freeze certain color, you can hold the button and release it when you find your favorite.
2. Press  to turn ON / OFF the night light at the bottom.
3. When the light is on, press  to adjust the brightness of the light (range: L01-L10)

Countdown Setting

1. Countdown switch

In the time display screen, press  to set countdown time,



Press   to set your desired time (range from 1~30MIN).

Press  to start counting down. If you want to stop it and return to time display screen. Just hold  for 2s to quit.

2. How to stop the bell rings?

- 1) Press any buttons to stop it.
- 2) The bell will ring for 60 seconds and stop automatically.

Volume Setting


In the time display screen, press   to set alarm volume range from (OFF - V01-V05). If you find the alarm is turned on unexpectedly and you don't need it, please set the volume to "OFF"

Daylight Saving Time

1. Press **DST** to turn ON / OFF AUTO DST, it's for daylight saving time area. It will automatically adjust displaying time on the 2nd Sunday of March and 1st Sunday of November. When it's ON, the screen will show "AUTO DST".
2. If your area doesn't apply to daylight saving time, please turn DST OFF.

Tips for remote control


Please aim at the product when using the remote control.



Settings without remote control





We recommend users to set by remote control.

For any reasons, if missing remote control, you can set up basic settings by pressing buttons on the device. However, functions like “Night light”, “DST”, “Countdown”, “Brightness setting”, “Display Colors”, “Volume” can only set by remote control.



Time Setting (by device buttons)





Note: we strongly recommend to set with remote control for the whole setting.

1. Press  button on the right of device to enter time setting. You will set in sequence for **12/24H mode > Hour > Minute > Year > Month > Date**
2. The “12H / 24H” is flashing, press   to select value.
Press  to confirm and next.
3. Then do the same for “Hour”, “Minute”, “Year”, “Month” and “Date”.

Note: You don't have to set the day of the week. It's calculated automatically.

Auto DST can only set by remote control.

Alarm Setting (by device buttons)

1. Press  to activate / inactivate alarm #1. You will see the icon  appears, that means alarm #1 is activated, while disappears means alarm #1 is inactivated.
2. Hold  button for 2 seconds to enter the alarm #1 setting, you will set in sequence for **Alarm Hour > Minute > Alarm Mode** (MON-SUN, MON-FRI, SAT-SUN). Press  button to confirm and next.
5. After setting Hour, Minute, you will need to choose alarm mode:
1-7 = Monday to Sunday, 1-5 = Monday to Friday, 6-7 = Saturday to Sunday
- 12 6. Alarm #2 can only set by remote control.

FAQ

This section summarizes the most common issues you may have. If you're unable to solve the issue, please feel free to contact ThreeDucksDirect@outlook.com.

Q1: The day of the week is wrong.

The day of the week is calculated automatically. Please check if the “Year”, “Month”, “Date” are set correctly. Many customers may have set a wrong “Year”. Please press “Time Set” button to enter time setting, pay attention to something like “2023” or “2024”. That's the year value, you have to set a correct year so that the day of the week will calculate correctly.

Q2: The alarm goes off unexpectedly. How can I turn it off permanently?

Sometimes other home device remote signal, like TV will influence the clock alarm. If you find the alarm turned on unexpectedly and you don't need it, please press the “Volume Down” button to set the volume “OFF”.

Q3: The temperature is inaccurate

The temperature is detected by the inside sensor. The inside circuit may produce heat, making it not so accurate as professional thermometer. It's normal. We need your understanding, after all this is not a professional device as thermometer.

Q4: The remote control doesn't work.

The remote control is powered by CR2032 battery. If it doesn't work, it may be run out of battery. Please try to replace CR2032 battery.

FAQ

Q5: The remote control is not sensitive.

The sensor is in the front of the device. When you press the remote control, please point directly to the front of the device.

Q6: The alarm doesn't go off at preset time.

Please check if your alarm mode is set to 1-5 (Monday to Friday). In this mode, it won't go off on Saturday and Sunday.

Warranty

Missing any accessories or any questions during usage, please contact us.
We provide lifetime warranty to every customer.

Contact us to activate your lifetime warranty Now!
Don't forget to include your order ID when contact.

Email

ThreeDucksDirect@outlook.com

Visit

www.jall-us.com